



**LOADERS SECTION- BACKHOE-WHEELED-TRACKED-SKID STEER**

**WHEEL / TRACKED LOADERS RECOMMENDED REPLACEMENT SEATING**

**AHLMANN, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
AS9	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
AS45	8020	7020	D7060 or D8060		Ditto
AS50	8020	7020	D7060 or D8060		Ditto
AS70	8020	7020	D7060 or D8060		Ditto
AS90	8020	7020	D7060 or D8060		Ditto
AS150	8020	7020	D7060 or D8060		Ditto
AS200	8020	7020	D7060 or D8060		Ditto
AF60E	8020	7020	D7060 or D8060		Ditto
AL7D	8020	7020	D7060 or D8060		Ditto
AL70E	8020	7020	D7060 or D8060		Ditto
AL85T	8020	7020	D7060 or D8060		Ditto
AL100T	8020	7020	D7060 or D8060		Ditto
AL100TI	8020	7020	D7060 or D8060		Ditto

**AMMAN YANMAR, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
V1	7020		D7060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
V3-5	7020		D7060		Ditto
V4-5	7020		D7060		Ditto

**ATLAS, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
82E	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
ATL32E	8020	7020	D7060 or D8060		Ditto
ATL42E	8020	7020	D7060 or D8060		Ditto
ATL50E	8020	7020	D7060 or D8060		Ditto
ATL52E	8020	7020	D7060 or D8060		Ditto
ATL52ES	8020	7020	D7060 or D8060		Ditto
ATL62E	8020	7020	D7060 or D8060		Ditto
ATL72E	8020	7020	D7060 or D8060		Ditto
ATL82E	8020	7020	D7060 or D8060		Ditto
AR35	8020	7020	D7060 or D8060		Ditto
AR41B	8020	7020	D7060 or D8060		Ditto
AR50	8020	7020	D7060 or D8060		Ditto
AR60	8020	7020	D7060 or D8060		Ditto
AR65	8020	7020	D7060 or D8060		Ditto
AR80	8020	7020	D7060 or D8060		Ditto
AR95	8020	7020	D7060 or D8060		Ditto

**CASE, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
621B	8020	7020	D7060 or D8060	Sears	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
721B	8020	7020	D7060 or D8060	Sears	Ditto
821B	8020	7020	D7060 or D8060	Sears	Ditto
921B	8020	7020	D7060 or D8060	Sears	Ditto

**CATERPILLAR, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
902	8020	7020	D7060 or D8060		If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
906	8020	7020	D7060 or D8060		Ditto
908	8020	7020	D7060 or D8060		Ditto
914G	5020		D5060 or 5050	KAB 515	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
924G	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
924F	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
928F	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
928G	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
936E	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
936F	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
938F	5020	8020	D5060 or D8060	SEARS (Contour or Comfort)or KAB	Ditto
938G	5020	8020	D5087 or D8087	SEARS (Contour or Comfort)or KAB	Ditto
950F	5020	8020	D5087 or D8087	SEARS (Contour or Comfort)or KAB	Ditto
950G	5020	8020	D5087 or D8087	SEARS (Contour or Comfort)or KAB	Ditto
960F	5020	8020	D5087 or D8087	SEARS (Contour or Comfort)or KAB	Ditto
962G	5020	8020	D5087 or D8087	SEARS (Contour or Comfort)or KAB	Ditto
966C	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
966D	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
966E	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
966F	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
966G	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
970F	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
972G	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
980G	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
988B	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
988F	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
988F-11	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
990	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
990-11	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
992C	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
992D	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
992G	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto
994D	5020 or 8020	D5060 or D8060	D5087 or D8087	SEARS (CAT Contour or Comfort)	Ditto

**DAEWOO, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
MEGA 200	5052 or 8052	5020	D5060 or D8060	SEARS 5052	5052 or 8052 is a direct replacement. Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**John Deere, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
244E&G	5052 or 8052	5020	D5060 or D8060	SEARS/John Deere DDH	5052 or 8052 is a direct replacement. Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
	5052	5020	D5060 or D8060	SEARS/John Deere DDH	5052 or 8052 is a direct replacement. Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
344E&G	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
444E&G	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
544E&G	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
644E&G	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
744E&G	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
244H	5052	5020	D5060 or D8060	SEARS/John Deere DDH	5052 or 8052 is a direct replacement. Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
344H	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
444H	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
544H	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
644H	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto
744H	5052	5020	D5060 or D8060	SEARS/John Deere DDH	Ditto

**Dresser Wheel loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
510C	5020		D5060 or 5050		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
512	5020		D5060 or 5050		Ditto
515C	5020		D5060 or 5050		Ditto
515CH	5020		D5060 or 5050		Ditto
518	5020		D5060 or 5050		Ditto
520C	5020		D5060 or 5050		Ditto
520CH	5020		D5060 or 5050		Ditto
525	5020		D5060 or 5050		Ditto
532	5020		D5060 or 5050		Ditto
538	5020		D5060 or 5050		Ditto
542	5020		D5060 or 5050		Ditto
545	5020		D5060 or 5050		Ditto
558	5020		D5060 or 5050		Ditto
560C	5020		D5060 or 5050		Ditto
568	5020		D5060 or 5050		Ditto

**FIATALLIS, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
FR70	5020		D5060 or 5050		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
FR90	5020		D5060 or 5050		Ditto
FR90PL	5020		D5060 or 5050		Ditto
FR100	5020		D5060 or 5050		Ditto
FR120	5020		D5060 or 5050		Ditto
FR130.2	5020		D5060 or 5050		Ditto
FR140.2	5020		D5060 or 5050		Ditto
FR160.2	5020		D5060 or 5050		Ditto
FR180.2	5020		D5060 or 5050		Ditto
FR220.2	5020		D5060 or 5050		Ditto

**Fiat-Hitachi, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
W450	7020 or 8020	5020	D7060 or D8060	KAB 555	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
W350	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W270	7020 or 8020	5020	D7060 or D8060	ISRI 6000/575	Ditto
W230	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W190	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W190 LB	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W170	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W170PL	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W130	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W130PL	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W110	7020 or 8020	5020	D7060 or D8060	KAB 555	Ditto
W90	7020 or 8020	7020	D7060 or D8060	DS85/90	Ditto
W80	7020 or 8020	7020	D7060 or D8060	DS85/90	Ditto
W70	7020 or 8020	7020	D7060 or D8060	DS85/90	Ditto
W60	7020 or 8020	7020	D7060 or D8060	DS85/90	Ditto
W50	7020 or 8020	7020	D7060 or D8060	DS85/90	Ditto

**FURUKAWA, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
355	7020 or 8020		D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**HALLA, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
HA170	7020 or 8020		D7060 or D8060	KAB	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**HANOMAG, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
6A	7020 or 8020		D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
15 F	7020 or 8020		D7060 or D8060		Ditto
66D	7020 or 8020		D7060 or D8060		Ditto
70E	7020 or 8020		D7060 or D8060		Ditto

**HYUNDAI, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
730	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
750	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
760	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
770	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
MODELS FROM 1996 : '3'	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	
730.3	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
740.3	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
750.3	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
760.3	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
770.3	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
780.3	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto

**JCB, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
406	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
407B	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
408B	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
409	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
415	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto
436HT	7020 or 8020	7020	D7060 or D8060	KAB 525 or 555	Ditto

**KAWASAKI, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
Z2	7020 or 8020		D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
Z3	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
50Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
60Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
65Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
65TM	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
70Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
80Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
85Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
90Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
95Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
115Z	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto
902A	7020 or 8020		D7060 or D8060	ISRI 6000/575	Ditto

**KOMATSU, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
WA65	7020 or 8020	7020	D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
WA65PT	7020 or 8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
WA75	7020 or 8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
WA85	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA90	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA95	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA120	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA180	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA180PT	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA270	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA270PT	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA320-A	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA240	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA450	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA470	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA500	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA600	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA700	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA800	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA900	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto
WA1200	7020 or 8020	7020	D7060 or D8060	KAB 525	Ditto

**KRAMER ALLRAD, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
312	7020		D7060	Grammer	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
320	7020	8020	D7060	Grammer	Ditto
420	7020	8020	D7060	Grammer	Ditto
512SL	7020		D7060	Grammer	Ditto
612	7020		D7060	Grammer	Ditto

**LIEBHERR, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
L-506	8020	7020	D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
L-507	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L-514	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L-538	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L-551	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L-564	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto

**MICHIGAN, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
L270	5052 or 8052	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
55B	5052 or 8052	7020	D7060 or D8060		Ditto

**O & K, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
L45B	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
L25.5	8020	7020	D7060 or D8060		Ditto
L15	8020	7020	D7060 or D8060		Ditto
600C					

**PICCINI, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
	8020	7020	D7060 or D8060	<b>MT</b>	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**SAMSUNG, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
SL180	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
SL330	8020	7020	D7060 or D8060		Ditto

**SCHAEFF, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
SKL 851	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**SCHOPF, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
L60	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**TAMROCK (TORO), Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
TORO 0010	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
EJC210D	8020	7020	D7060 or D8060		Ditto
EJC430	8020	7020	D7060 or D8060		Ditto
TORO 650D	8020	7020	D7060 or D8060		Ditto

**TEREX, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
TM200-R	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").

**VOLVO, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
L330D	8020	7020	D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
L220E	8020	7020	D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
L180D	8020	7020	D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
L160	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L150	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L150C	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L150D	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L120B	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L120C	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L120D	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L90B	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L90C	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L90D	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L70D	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L50D	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L45	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L40B	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L35B	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L32B	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L30B	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L302C	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L402C	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto
L502C	8020	7020	D7060 or D8060	ISRI 6000/575	Ditto

**ZEPPELIN, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
ZL8B	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
ZL10B	8020	7020	D7060 or D8060		Ditto

**ZETTLMEYER, Wheeled Loaders**

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
402	8020	7020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
601B	8020	7020	D7060 or D8060		Ditto
602	8020	7020	D7060 or D8060		Ditto
602B	8020	7020	D7060 or D8060		Ditto
602C	8020	7020	D7060 or D8060		Ditto
702	8020	7020	D7060 or D8060		Ditto
802	8020	7020	D7060 or D8060		Ditto
1002i	8020	7020	D7060 or D8060		Ditto
1801	8020	7020	D7060 or D8060		Ditto
2002	8020	7020	D7060 or D8060		Ditto
5002	8020	7020	D7060 or D8060		Ditto

## CRAWLER LOADERS - RECOMMENDED REPLACEMENT SEATING

### CATERPILLAR - Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
933LGP	8020	D7060 or D8060	D8087	Sears (CAT Contour)	If replacing a CAT Contour or Comfort seat (bolt pattern 395mm x 402mm). Kit SA19236.901 is required. Unless a D5087 or D8087 is used (direct replacement)
933	8020	D7060 or D8060	D8087	Sears (CAT Contour)	
935B	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
935C	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
939	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
951B	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
951C	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
953	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
953C	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
955K	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
955L	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
963	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
963B	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
963C	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
973	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
955L	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
963B	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto
973B	8020	D7060 or D8060	D8087	Sears (CAT Contour)	Ditto

### JOHN DEERE, Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
450C	5052	8052	D8087	Sears (JD DDH)	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
455G Series 1V	5052	8052	D8087	Sears (JD DDH)	
55G Series 1V	5052	8052	D8087	Sears (JD DDH)	Ditto

### DRESSER - Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
100G	5020	8020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
125G	5020	8020	D7060 or D8060		
175G	5020	8020	D7060 or D8060		Ditto

### DRESSTA, Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
	8020		D7060 or D8060	DS85/90	Ditto

### FIAT-HITACHI, Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
FL175	5020	8020	D7060 or D8060	KAB	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
FL145	5020	8020	D7060 or D8060	KAB	

### KOMATSU, Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
D575S-1	5020	8020	D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
D66S-1	5020	8020	D7060 or D8060		
D75S-1	5020	8020	D7060 or D8060		Installation kit SA19096.901 required

### LIEBHERR, Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
752	8020		D7060 or D8060	ISRI 6000/575	Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").
755	8020		D7060 or D8060	ISRI 6000/575	

### TAKEUCHI, Crawler Loaders

MODEL	OPTION 1	OPTION 2	OPTION 3 (Air Option)	OEM SEAT	COMMENTS
L1226	8020		D7060 or D8060		Installation kit SA19096.901 required. This kit accommodates all bolt patterns up to 355 wide x 395mm (14 x15.5").